



How to Update Firmware through Web Interface

1. Set IP address to 169.254.111.111 subnet mask: 255.255.0.0 ([if you can't browse device ip](#))
2. Run Bonjour Browser.exe to seek target device at Web Server (HTTP) icon.



3. Double click the target device in Bonjour browser. And it will get in device webUI.
4. Select “System” -> “Update Firmware:”.
5. Click the “Choose File” button.
6. Select the firmware file for web update. The firmware files are normally named webfwh.bin for host and webfwc.bin for client.
7. Press “Upload” button.
8. Web update process will start. Device will go to link off state and the firmware update process may takes a few minutes.



System | Video Wall | Network | Functions

▸ Version Information:

▾ Update Firmware:

Firmware Update Progress:

```
firmware file name: webfwh.bin
firmware file size: 4484327 bytes
Decompressing firmware...
Start programming flash...
programming bootloader...
programming kernel...
```

Please wait... 9 %

System | Video Wall | Network | Functions

▸ Version Information:

▾ Update Firmware:

Firmware Update Progress:

```
firmware file name: webfwh.bin
firmware file size: 4484327 bytes
Decompressing firmware...
Start programming flash...
programming bootloader...
programming kernel...
programming rootfs...
programming rootfs patch...
programming parameters...
Programming completed
```

DONE. Rebooting...